
INSTRUCTIONS FOR ASSEMBLING AND DISASSEMBLING BACKFACER ROUTER 20-BF10



Insert 1/8 Allan key (A) into pin hole (F) to lock flange from turning. Remove 2 screws holding dust pipe (B) to rectangular plate. Remove B. Insert router (C) into tool flange and turn slightly until router locks into flange and will not turn. Insert locking bolt (D) into end of router and push all the way down to end of router until bolt reaches flange. Using 1/4 Allan key (E) tighter bolt clockwise. This bolt locks router into tool. Remove 1/8 Allan key. Spin router by hand to check if secure.

To remove router from tool, insert 1/8 Allan key into pin hole (**F**) to lock flange. Using 1/4 Allan key, unscrew bolt from center of router (counterclockwise). Pull out router and replace, if necessary.